

Door Downsizing Guide

Door Type	Hinge Side	Lock / Strike Side	Total
Hemmed Beveled Single	1/8"	1/8"	1/4"
Hemmed Beveled Pair with Z Astragal	1/8"	1/8"	1/4"
Hemmed Beveled Pair with Flat Astragal	1/8"	3/32"	7/32"
Hemmed Beveled Pair with No Astragal	1/8"	3/32"	7/32"
Hemmed Beveled Pair with Rem. Mullion	1/8"	3/32"	7/32"
Hemmed Beveled Pair Double Egress	1/8"	3/32"	7/32"
Butt Square Edge Single	1/8"	1/8"	1/4"
Butt Square Edge Pair with Z Astragal	1/8"	3/16"	5/16"
Butt Square Edge Pair with Flat Astragal	1/8"	3/32"	7/32"
Butt Square Edge Pair with No Astragal	1/8"	3/32"	7/32"
Butt Square Edge Pair with Rem. Mullion	1/8"	3/32"	7/32"
Butt Square Edge Pair Double Egress	1/8"	3/32"	7/32"